

## PurTest® PESTICIDE TEST

The PurTest® Pesticide Test detects two of the most common pesticides used in the U.S at or below the EPA Maximum Contaminant Level (atrazine - 3 ppb and simazine - 4 ppb)

### Instructions For Use:

1. Open foil packet and take out all contents.  
The packet contains (1) pesticide test strip, (1) test vial, (1) dropper pipette and a dessicant packet (to be discarded).
2. Collect water into a clean glass or directly into dropper pipette.
3. Using the dropper pipette, dispense one to two (1-2) drops of water into test vial.
- 4 Place the test strip into test vial, with arrows pointing DOWN.
5. Wait 10 minutes. DO NOT DISTURB strip or vial during this time. Blue lines will appear on strips.
6. Take strip out of the vial and read results:

### Negative:

Bottom line (next to number 1) is darker than top line (next to number 2).



### Positive:

Top line (next to number 2) is darker than bottom line (next to number 1) or lines are equally dark.



6. NOTE: If no lines appear, or both lines are very light, the test did not run properly and the result is not valid. If a test strip shows a positive result, your water sample may contain pesticides at a toxic level.

**Results questions? Visit [www.purtest.com](http://www.purtest.com)**